


511BH SLAVE CYLINDER



511 BH SLAVE CYLINDER

NUMBER	DESCRIPTION	PART NUMBER	QTY
1	CYLINDER	CY - 5511	1
2	END CAP FREE END	EC - 6103	1
3	END CAP MOUNTING END	EC - 6104	1
4	WIPER	LDW-00625	2
5	O-RING	RVO-114	3
6	O-RING	RVO-218	2
7	O-RING	RVO-216	3
8	TILLER PLATE	MO-5513	1
9	SCREW	SC-10155	2
10	O-RING	RVO-014	1
11	TILLER STUD	ST-6318	1
12	TILLER ARM BUSH	BU-6314	2
13	TILLER ARM	TA-5514	1
14	WASHER 1/2"x1"X16G-304 S/S	WA-10136	3
15	NUT 1/2" UNFx8.0 NYLOC 304 S/S	NU-10185	1
16	NUT 3/8" UNF NYLOC 316 S/S	NU-10139	1
17	NUT 3/8" UNF NYLOC 316 S/S	NU-10133	2
18	WASHER 3/8"x3/4x18G-304 S/S	WA-10135	2
19	TILLER BOLT BUSH	BU-5507	2
20	BOLT 3/8"x1 1/2" S/S	SC-10315	1
21	BLEEDER TEE 3/8" COMPLETE	BL-10186A	2
22	PISTON ROD	PR-6442	1
23	PISTON	PI-6445	1
24	DOWEL PIN 3/16"x7/8"	DO-10184	1
25	TILT TUBE ROD	SH-6164	1
26	BULL HORN	BH-6165	2
27	1/2" UNC LOCKNUT	NU-10134	2
28	ADJUSTING NUT	NU-6172	2
29	GRUB SCREW 10x24UNCx1/4" S/S	SC-10137	2
30	SPACER 3mm	BU-6156	2
31	SPACER 12mm	BU-6173	2
32			
33			
34			